

MASS TRANSIT STINGER POWER SUPPLY

Our stinger power supplies are designed specifically for the rigors of a mass transit maintenance yard. These units provide 1000 volts of DC for train maintenance. They are built to ANSI C34.2 and UL 508 standards for dependable, reliable, and safe operation. Units are available with output capacities ranging from 50 kW to 500 kW. All maintenance and repairs are performed through the front doors allowing the unit to be located with zero clearance along walls.



Features

- AC and DC metering
- Fully Fused and Interlocked for Safety
- Fork Lift Base with Boltdown Provisions
- All Copper Conductors
- Air Cooled
- Outputs can be controlled locally as well as remotely
- Flashing Beacon when Outputs are Energized

Options

- 1-4 Outputs with separate controls
- Regenerative Braking
- Casters